







REMOVE TV FROM FLOOR STAND

- Fernsehgerät vom Standfuß nehmen
- Retirez la télévision du pied de sol
- TV verwijderen van vloerstandaard
- Quite el televisor del soporte de suelo
- Rimuovere la TV dal piedistallo
- Retire a TV do suporte de chão
- Avlågna TV:n från golvstativet
- Zdejmij telewizor ze stojaka podłogowego
- Снять телевизор с подставки

- Odstraňte televíziu z podlahového stojanu
- Odstráňte televizor z podlahového stojanu
- A TV eltávolítása a padlóállványról
- Scoateți televizorul din suportul de podaa
- Зніміть телевізор з підставки
- Свалете телевизор от подовата стойка
- フロア・スタンドからテレビを取り外す



OPTIONAL POSITIONS



EFF 8340



Important
Wichtig
Important
Belangrijk
Important
Importante
Viktigt
Ważne
Важно
Důležité
Dôležité
Fontos
Önemli
Important

Для монтажу необхідно 2 людини Important

Важливо
重要

Mounting instructions
Montageanleitung
Consignes d'installation
Montagevoorschrift
Instrucciones de montaje
Istruzioni di montaggio

Manual de montagem
Montageföreskrifter
Instrukcja montażu
Инструкция по сборке и установке
Návod k montáži


Návod na montáž
Szerelési előírás
Montaj kılavuzu
Instrucțiuni de montaj
Вказівки по монтажі
設置の説明書

1 2 3 4 5

MOUNTING INSTRUCTIONS

Visit www.vogels.com for more information

PARTS INCLUDED



TOOLS REQUIRED NOT INCLUDED



2 persons required
Zwei Personen erforderlich
Nécessite deux personnes
2 personen
Se precisan dos personas
E' richiesta la presenza di due persone
Requer duas pessoas
Två personer erfordras
Konieczne dwie osoby
Нужны два человека
Montáž vyžaduje 2 osoby
Montáž vyžaduje 2 osoby
Két személy szükséges
Iki kişi gerekir
Este nevoie de două persoane
Для монтажу необхідно 2 людини
Необходими са двама души
二人作業



MADE IN THE NETHERLANDS
VOGELS PRODUCTS BY
NL 5428 DB EINDHOVEN
WWW.VOGELS.COM

1

REMOVE TAPE

K

This diagram shows the first step of the installation process. A yellow rectangular piece of tape, labeled 'K', is being removed from the back of a white seat cushion. A large yellow arrow points upwards from the cushion towards the tape, indicating the direction of removal. The text 'REMOVE TAPE' is written above the tape.

4 4.1

A

max. 10 kg

B

max. 10 kg

2.3

Diagram 2.3 illustrates the mounting of the TV on the wall plate. The diagram shows the TV being attached to a wall plate with screws. A detailed view shows the TV being inserted into the wall plate. A table lists the required screws: L (screw), M (screw), N (screw), and TV (TV screw). A note indicates that the TV screw is not required for the TV.

Option	TV
L	TV
M	TV
N	TV
TV	TV

4.2

2.4

2.5

The diagram illustrates the process of mounting the window frame to the wall. The main illustration shows a yellow frame being secured with screws (F) into a wall. An inset shows a close-up of a screw being driven into the frame (W) with a drill (I). To the right, a detail view shows the frame's edge with a gap of $\pm 1''$ between the frame (F) and the wall (H).

4.4

4.5

OPTION

Standard

Option 1

Option 2

Max. 3x

SEE - OPTIONAL POSITIONS

5.2